

Remote Access Gateway IGW/910 *with DNP/9535*

Hardware Reference



SSV Software Systems GmbH

Dünenweg 5
D-30419 Hannover
Phone: +49 (0)511/40 000-0
Fax: +49 (0)511/40 000-40
Email: sales@ssv-embedded.de

Document Revision: 1.0
Date: 2019-12-11

CONTENT

1	INTRODUCTION	3
1.1	Safety Guidelines	3
1.2	Conventions	3
1.3	Block Diagram	4
1.4	Features and Technical Data	5
2	OVERVIEW	6
3	PINOUPS	7
3.1	Ethernet Interface.....	7
3.2	Screw Terminals.....	7
3.3	COM Ports 1..8 (D-Sub DB25 male)	8
3.4	COM Port 9 (D-Sub DE9 male)	9
3.5	COM Port 10 (D-Sub DE9 male)	9
4	LINUX DEVICE MAP	10
5	HELPFUL LITERATURE	11
	CONTACT	11
	DOCUMENT HISTORY	11

1 INTRODUCTION

This document describes the basic hardware components of the Remote Access Gateway IGW/910.

1.1 Safety Guidelines



Please read the following safety guidelines carefully! In case of property or personal damage by not paying attention to this manual and/or by incorrect handling, we do not assume liability. In such cases any warranty claim expires.

- The power supply should be in immediate proximity to the device.
- The power supply must provide a stable output voltage at 12..24 VDC $\pm 10\%$. The output power should be at least 7 W.
- Please pay attention that the power cord or other cables are not squeezed or damaged in any way when you set up the device.
- Do NOT turn on the power supply while connecting any cables, especially the power cables. This could cause damaged device components! First connect the cables and THEN turn the power supply on.
- The installation of the device should be done only by qualified personnel.
- Discharge yourself electrostatic before you work with the device, e.g. by touching a heater of metal, to avoid damages.
- Stay grounded while working with the device to avoid damage through electrostatic discharge.
- The case of the device should be opened only by qualified personnel.

1.2 Conventions

Convention	Usage
bold	Important terms and information
<i>monospace</i>	Filenames, Pathnames, program code, command lines

Table 1: Conventions used in this document

1.3 Block Diagram





Figure 1: Block diagram of Remote Access Gateway IGW/910

1.4 Features and Technical Data

Processor	
Manufacturer / Type	Atmel ATSAM-A5D35 SoC
Clock speed	528 MHz
Memory	
RAM	256 MB SDRAM
Flash	4 MB NOR memory
Storage media	1x internal microSD card holder
Interfaces	
Ethernet	1x 10/100 Mbps (RJ45)
Debug Port	1x (screw terminal)
Serial I/Os	1x D-Sub DB25 (COM 1..8) 1x D-Sub DE9 (COM 9) 1x D-Sub DE9 (COM 10)
Special Functions	
Watchdog	1x Timer watchdog (hardware-based, software-configurable) 1x Power supervisor (hardware-based)
Displays / Control Elements	
LEDs	1x Power 1x System status (programmable) 1x LAN LED for Ethernet interface
Electrical Characteristics	
Power supply range	12 .. 24 VDC \pm 10% from external power supply
Power consumption	< 7 W
Mechanical Characteristics	
Protection class	IP20 industrial case for 35 mm DIN-rail mounting
Mass	< 210 g
Dimensions	112 mm x 100 mm x 45 mm
Operating temperature	0 .. 60 °C
Storage temperature	-40 .. 85 °C
Standards and Certifications	
EMC	CE
Environmental standards	RoHS, WEEE

2 OVERVIEW



- | | |
|-----------------------------------|--------------------------------|
| ① Screw Terminals (Power & Debug) | ⑤ DIN-Rail Mounting (backside) |
| ② Power LED & User LED S1 | ⑥ COM Port 10 |
| ③ COM Ports 1..8 | ⑦ Ethernet Interface LAN 1 |
| ④ COM Port 9 | |

Figure 2: Overview Remote Access Gateway IGW/910

3 PINOUTS

3.1 Ethernet Interface

Pin	Name	Function
1	TX+	10/100 Mbps LAN, TX+
2	TX-	10/100 Mbps LAN, TX-
3	RX+	10/100 Mbps LAN, RX+
4	---	Bob-Smith Termination
5	---	Bob-Smith Termination
6	RX-	10/100 Mbps LAN, RX-
7	---	Bob-Smith Termination
8	---	Bob-Smith Termination

Table 2: Pinout Ethernet interface



LED	Function
Green (top)	10/100BASE-T link/activity
Yellow (bottom)	Not Connected

Table 3: Ethernet LED functions

3.2 Screw Terminals

Terminal	Function
A1	Debug Port TXD
A2	Debug Port RXD
A3	Vin 12..24 VDC ±10%
A4	Ground


Table 4: Pinout screw terminals

The debug port allows to access the DIL/NetPC DNP/9535 with a serial console.

3.3 COM Ports 1..8 (D-Sub DB25 male)

Pin	Name	Function
1	GND	Ground
14	RXD1	COM1 Serial Port: RS232 RXD
2	TXD1	COM1 Serial Port: RS232 TXD
15	GND	Ground
3	RXD2	COM2 Serial Port: RS232 RXD
16	TXD2	COM2 Serial Port: RS232 TXD
4	GND	Ground
17	RXD3	COM3 Serial Port: RS232 RXD
5	TXD3	COM3 Serial Port: RS232 TXD
18	GND	Ground
6	RXD4	COM4 Serial Port: RS232 RXD
19	TXD4	COM4 Serial Port: RS232 TXD
7	GND	Ground
20	RXD5	COM5 Serial Port: RS232 RXD
8	TXD5	COM5 Serial Port: RS232 TXD
21	GND	Ground
9	RXD6	COM6 Serial Port: RS232 RXD
22	TXD6	COM6 Serial Port: RS232 TXD
10	GND	Ground
23	RXD7	COM7 Serial Port: RS232 RXD
11	TXD7	COM7 Serial Port: RS232 TXD
24	GND	Ground
12	RXD8	COM8 Serial Port: RS232 RXD
25	TXD8	COM8 Serial Port: RS232 TXD
13	---	Not connected


Table 5: Pinout COM Ports 1..8



3.4 COM Port 9 (D-Sub DE9 male)

Pin	Name	Function
1	---	Not connected
2	RXD9	COM9 Serial Port: RS232 RXD
3	TXD9	COM9 Serial Port: RS232 TXD
4	---	Not connected
5	GND	Ground
6	---	Not connected
7	---	Not connected
8	---	Not connected
9	---	Not connected


Table 6: Pinout COM Port 9



3.5 COM Port 10 (D-Sub DE9 male)

Pin	Name	Function
1	---	Not connected
2	RXD10	COM10 Serial Port: RS232 RXD
3	TXD10	COM10 Serial Port: RS232 TXD
4	---	Not connected
5	GND	Ground
6	---	Not connected
7	---	Not connected
8	---	Not connected
9	---	Not connected

Table 7: Pinout COM Port 10



4 LINUX DEVICE MAP

This table shows which Linux device name is assigned to which interface of the IGW/910.

Interface Name	Linux Device Name	Note
LAN 1	eth0	
Debug Port	ttyS0	Linux console for debug, RS232 on DNP
COM 1	ttyUSB0	Serial port on quad UART 1
COM 2	ttyUSB1	Serial port on quad UART 1
COM 3	ttyUSB2	Serial port on quad UART 1
COM 4	ttyUSB3	Serial port on quad UART 1
COM 5	ttyUSB4	Serial port on quad UART 2
COM 6	ttyUSB5	Serial port on quad UART 2
COM 7	ttyUSB6	Serial port on quad UART 2
COM 8	ttyUSB7	Serial port on quad UART 2
COM 9	ttyUSB8	Serial port on quad UART 3
COM 10	ttyUSB9	Serial port on quad UART 3

Table 8: Linux device map

5 HELPFUL LITERATURE

- DNP/9535 hardware reference
- SSV Web ConfigTool User Manual

CONTACT

SSV Software Systems GmbH

Dünenweg 5
D-30419 Hannover

Phone: +49 (0)511/40 000-0
Fax: +49 (0)511/40 000-40
E-mail: sales@ssv-embedded.de

Internet: www.ssv-embedded.de
Forum: www.ssv-comm.de/forum

DOCUMENT HISTORY

Revision	Date	Remarks	Name	Review
1.0	2019-12-11	First version	WBU	FKI

The content of this document can change any time without announcement. There is taken over no guarantee for the accuracy of the statements. The user assumes the entire risk as to the accuracy and the use of this document. Information in this document is provided 'as is' without warranty of any kind. Some names within this document can be trademarks of their respective holders.

© 2019 SSV SOFTWARE SYSTEMS GmbH. All rights reserved.